



COSMEDICO TECHNICAL ADVISORY: Cosmedico Lamp Exposure Schedule

Exposure Guidelines

The maximum exposure time for any piece of equipment is determined by both the lamp used and the specifics of the bed or booth. However, experience shows us that is possible to broadly define a lamp by 'exposure time'. This chart gives a general indicator of appropriate applications for our most popular lamp types.

Full-Coat Lamps 80/100w		TYPICAL EXPOSURE TIME				
COSMEDICO LAMP FAMILY	8-14 min.	12-18 min.	16-24 min.	20-26 min.	24-30 min.	
Hi-Tan®	✓					
CosmoLux® ESP®		✓				
CosmoSun 515 (500 HOUR LAMP)		✓				
Goldarium® SP			✓			
CosmoSun 520 (500 HOUR LAMP)			✓			
CosmoStar® Longlife				✓		
CosmoLux® UVA plus					✓	

Reflector Lamps 80/100/120w		TYPICAL EXPOSURE TIME				
COSMEDICO LAMP FAMILY	9-13 min.	12-16 min.	13-17 min.	15-20 min.	20-30 min.	
CosmoLux® ESP®/R	✓					
CosmoLux® VLR® TT		✓				
CosmoLux® VLR®			✓			
Goldarium® SR				✓		
CosmoLux® RA plus					✓	

Reflector Lamps 140/160/180w		TYPICAL EXPOSURE TIME	
COSMEDICO LAMP FAMILY		7-12 min.	9-15 min.
CosmoLux® VHR® TT		✓	
CosmoLux® VHR®			✓

CAUTION: This is not intended as a recommendation that Cosmedico lamps can always be used within these guidelines. Please consult the bed or booth equipment owner's manual and Cosmedico's published compatibility listings before selecting any Cosmedico product.

For more information, visit our website at www.cosmedico.com